

muRata

Keysight PathWave RF Synthesis (Genesys) Install manual

Murata Manufacturing Company, Ltd. 10 February 2020



0. Contents



1.	About this manual	…p.4
2.	Operation environment	…p.5
3.	The type of Genesys library	…p.6
4.	How to get the update library	…p.7
5.	Note:Cautions when installing	p.8
6.	How to install the update library	…p.9
7.	Part Selector	p.10
8.	How to use the library	…p.12
9.	Contact us	…p.16



Murata Manufacturing Co., Ltd. ("Murata") provides the simulation library for Keysight PathWave RF Synthesis (Genesys). This manual describes how to install this simulation library ("Library") and how to use it.

This manual describes valid procedures, but depending on your environment, please note that some operations may differ partially.

In this manual, PathWave RF Synthesis (Genesys) is simply referred to as Genesys.



- This manual describes procedures based on the following environment. Please refer to the manuals for the PC, etc. used in the actual environment.
 - OS: Windows 10
 - It is necessary to have the administrative right to install the library.
 - Genesys version: 2018, 2020



There are two types of Genesys libraries.

[1]. Library built into Genesys in advance[2]. Library obtained from Murata website

After here, we call [1] the built-in library, and [2] the update library.


The built-in libraries can NOT update. If you continue to use the built-in library, you have a risk of simulating with the information of the product that has been discontinued.

For this reason, we highly recommend you to use the latest update library.

*Be sure to read the notes in Chapter 5 when installing the update library.

4. How to get the update library





There are two ways to install the update library.

[1] Get from Murata library page Open a browser and get the library from the following address:

https://www.murata.com/en-us/tool/librarydata/librarykeysight3

[2] Get it from the Genesys menu Select Murata on Current Library.

Right-click the "_Click To Update" at the top of the Part Selector menu.

Left-click "Update Library" in the pull-down menu. The browser will be launched and the same site as [1] will open. Please download the desired library.

Read the notes on the following page when installing the update library that was obtained.



After here, we'll describe procedures in Genesys 2018. If you use Genesys 2020, please replace Genesys2018 into Genesys2020.


The Genesys library is put in the following folders. But when you install the update library, these folders are made to delete. If you already put customized models in these folders, please be sure to copy them before installing.

C:¥Users¥<User>¥AppData¥Local¥Keysight¥Genesys2018¥Data¥Murata C:¥Users¥< User >¥AppData¥Local¥Keysight¥Genesys2018¥Library Files¥Murata

6. How to install the update library




Please double-click Murata_Genesys2018_(date)_Installer.exe, and then the installer will be launched as shown on the left.



After clicking Next -> Install, the progress bar will be displayed in a couple of minutes as shown on the right. When the progress bar finishes, please click Finish button. The installation is now complete.


7. Part Selector(1/2)





7. Part Selector(2/2)





You can narrow down the list by purpose. Capacitor for Automotive Purpose Capacitor for General Purpose Capacitor for Medical Purpose Inductor for Automotive Purpose Inductor for General Purpose

Part Selector A	×
Current Library:	
Murata	\sim
Category:	
<all></all>	\sim
0 💣 🍫	
Filter By:	
47p	>
Name	^
	- 11
GCM0331C1E470JA01 (47pF)	

You can also filter the list by capacitance or inductance.

8. How to use the library(analysis condition) meRata


We will describe how to set up the analysis condition. Please select New Item in Workspace Tree->Analysis->Linear Analysis. After entering frequency range etc., please click OK button.

k is the factor is in the factor is i	Sch1]						- D X
With the Adapting Image: The Adapting of the Ada							_ 8 ×
With the definition Address Address Balance Bedden Bedden Bedden	i 🔁 💕 🛃 👗 📭 💏 🜮 🖤	(*) 🗳 😢 🖪 🖪 🖶 ▷ • ① : 🎌 🔛	🛯 👁 ጌ 💠 📐 🗇 🔍 🦵	🖸 🐼 💠 🌣 🖄 🏠 🏠 🖬 🔛 🖓 🐼 🖉			
Image:							
Image:		• • • • • • • • • • • • • • • •					Part Selector A X
Page Atticst ondergin. Page Fig Linear Analysis Properties Viewer Expanse Vi							Current Library:
Sig Linear Analysis Properties Nature Data Data <t< th=""><th></th><th></th><th></th><th></th><th></th><th></th><th></th></t<>							
Building Build		Add Linear Analysis	· · · · · · · · · · · · · · · · · · ·				
<pre></pre>	Designs > t=	DC Analysis		St. Lincon Analysis Descention	~		
Image:				1 Linear Analysis Properties	^		
Unit Unit Unit Exercision: Effection: Effe	- · · · · · · · · · · · · · · · · · · ·						
Image: Section	· · · · ·			Name: Linear1			
Weischen Bigespreise Singel Image: Singel <td< th=""><th></th><th>· · · · · · · · · · · · · · · · · · ·</th><th></th><th></th><th>Erequency Units: Hz V</th><th></th><th></th></td<>		· · · · · · · · · · · · · · · · · · ·			Erequency Units: Hz V		
Image:	· · · · · · · · · · · · · · · · · · ·	Momentum Analysis		Design: Sch1			Name
Both Dataget:		RF System Analysis		Design.			Click To Update
Image: State Stat	🗹 Graph	Sonnet Analysis		Dataset	Automatic Recalculation		
Image: Server Adapter Image: Server Adapter Image: Server Adapter Image: Server Adapter <th>EiveReport</th> <th>TESTLINK™ Analysis</th> <th> -</th> <th>Dataset:</th> <th>- A<u>a</u>tomade Recalculation</th> <th></th> <th></th>	EiveReport	TESTLINK™ Analysis	-	Dataset:	- A <u>a</u> tomade Recalculation		
Cer al Bross C	1993 A.						
Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: Statestands Image: S]	Description:	Calculate Now		
With Marken Implementation Implement							
winder Implicit State Implicit Stat					Hactory Defaults		
Immutantian	[]1] lable				· · · ·		
View	🔄 From Library			DC Andreise (1.5.10)	A Save as Equarite		
View Underwork Image: Start: 100 + Hz View Underwork Start: 100 + Hz Start: 100 + Hz Start: 100 + Hz Image: 100 + Hz Start: 100 + Hz				DC Analysis: (default)	V Save as rayonce		
Image: State in the state					Type Of Sween		
Frequency Range Uprear: Number of Points: 51 Image: Start: 100 Hz Image: Start: Start: Image: Start:					Type of Sweep		
Image: State 1 State 1::::::::::::::::::::::::::::::::::::				Frequency Range	C Linear: Number of Points: 51		
Image: State State Image: State Image: State State Image: State St				requercy runge	0		
Step: 6 +9 + 1z O Linear: Step Sige (+1z): 1 + 04543A003300/m. ************************************				Start: 100 Hz	I og: Points/Decade:		
Stop: bet+9 H2 Uters: Lef6 H= 6343A MOSGROW Furcesties 55 55 C Uters: Clear List H= 6343A MOSGROW Foresties 55 7 Clear List H= 6343A MOSGROW H= 6343A MOSGROW Foresties 55 C OK Cancel H= base H= case MOSGROW Swed Ture States Fore Image: State Fore OK Cancel H= base H= case MOSGROW Swed Ture States Fore Image: State Fore Image: State Ima					Gradit 21		
Vereable Image: Contract Mark States Vereable Image: Contra	A 🔍 💷 🗖 🗛			Stop: 6e±0 Hz	O Lineary Step Size (Hz)		
Percentives Image: State S				3100. 0000 112			
None Advanced Gmin: 100e-12 Gmin: 100e-12 Preferred Reduction Size: 18 Imperature: 16.85 OK Cancel Get Herp Imperature: State Imperature: Imperature: 16.85 Imperature:							
Image: Top				Advanced	Clear List		
Saved Tune States	None						
Saved Ture States				Gmin: 100e-12 S V			
Preferred Reduction Size: 18 Imperature: 16.85 °C Concel Emperature: 16.							
Seved Ture States				Preferred Reduction Size: 18	U		
Saved Tune States tros tros tros tros tros tros tros tro				riciaria Reduction size. 10			
Saved Tune States tros tros tros tros tros tros tros tro							<u>^</u>
Saved Tune States tros tros tros tros tros tros tros tro				Terrent 16.95 00	OK Consul @		
Saved Tune States Errors Image: Clear All Errors (0) Image: Clear All Errors Show Graph and Table Errors (0) Errors Clear All Errors (0) Errors Clear All Errors (0) Errors Command Prompt (MATIAES Script) Simulation Log Equation Debug				Temperature: 10.85	OK Cancel Ve Help		
Saved Tune States Errors Image: Clear All Errors (0) Image: Clear All Errors Show Graph and Table Errors (0) Errors Clear All Errors (0) Errors Clear All Errors (0) Errors Command Prompt (MATIAES Script) Simulation Log Equation Debug							
Saved Tune States Errors Image: State			· · · · · · · · · · · · · · · · · · ·			<mark></mark>	~ · · ·
Saved Tune States Errors Image: State		El Destrict Done or					
Image: Solution (AutoRecaic) Type Error Location Analyses To Run (AutoRecaic) Image: Solution Content of the Errors (Image: Solution Contentof the Errors (1	C3 Farther Ly- schematic					Library Se Part Selec Workspac Design Va
Analyses To Run (AutoRecalc) Analyses To Run (AutoRecalc) Cear All Errors Command Prompt (MATLAB Script) Simulation Log Equation Debug Search Results	Saved Tune States 🔹	Errors					
	📔 🛛 🗞 🕺	Туре		Error	Location		
Errors Command Prompt (MATLAB Script) Simulation Log Equation Debug Search Results	Analyses To Run (AutoRecalc)						
Errors Command Prompt (MATLAB Script) Simulation Log Equation Debug Search Results							
Errors Command Prompt (MATLAB Script) Simulation Log Equation Debug Search Results							
		Clear All Errors Show Graph					
Ready CAP NUM SCRU		Errors Command Prompt (MATLAB Script)	Simulation Log Equation Debug S	Search Results			
	Ready						CAP NUM SCRL

8. How to use the library (schematic)



You can put the element on the schematic by selecting component from Part Selector and operating drag-and-drop. After putting Ports at both ends of the element, please click the ▶ button.



8. How to use the library (describe the result)



 \times

We'll show how to set up the graph properties. Firstly, please click the New Item in the Workspace, and chose Graph. You can add a new graph by clicking Add button. And then you can adjust graph properties.

🔀 Graph1 Properties	×	Graph Series Wizard (Locked Grap	oh Mode)		×
Name: Graph 1 Graph 1 Graph 1 Graph 1	~	Type of Series Selected:	Data Selected:	<none></none>	~
Graph Title: Show All Columns Oon text Variable Optional Ritht Hide? Color Type Edit Remove Linear1_Sch1_Data S Image: Second		General	GRM155R71H104KE		
X-Axis Auto-Scale Min: 100 Max: 10e +9 Units: Hz # Ugarithmic Label: # Divisions: 10 # Advanced OK Cancel Help		More Measurements	<u>∮</u> Edi	it Equations	

OK

Cancel


Help

Plot On Right Y-Axis Clear Mode

8. How to use the library (example)



Part Number : GRM155R71H104KE14





- https://www.murata.com/ja-jp/contactform
- (English) (中文)

 - https://www.murata.com/zh-cn/support/contact

https://www.murata.com/ko-kr/contactform

- https://www.murata.com/en-us/contactform

If you have any questions about this library, please contact us through the links below.



•



(한국어)

(日本語)

15



END